

Assembly instructions, maintenance and safety information

Batch no.

Miri Sticks

CE UK
CA




Triclimb®

Triclimb

Triclimb – Miri Sticks

Climbing/ball run rungs x 6



IMPORTANT - Retain these instructions for future reference. 2021 V1

The Miri Sticks are designed to be added to the Miri reversible activity board primarily as climbing grips. No tools are needed to connect or disconnect the sticks - simply push into place. The Miri sticks are designed to be easily removed.

If using the MIRI as a ball run: The higher the position of the Miri slide on the Triclimb frame, the smaller the balls that are needed to achieve best results. Please also note that the sticks can be inserted either way around; for best results if using the sticks as part of a ball run, please ensure the short end (A) is located close to the side rail.



WARNINGS

*It is extremely important that you read and retain the information in this WARNINGS section to reduce the risk of injury.

*Children must be supervised at all times while using the Triclimb products.

*Only use the Triclimb products for their intended purpose. Due to the finishes used, the products are for indoor use only in a domestic setting.

*Never allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-frame or to attach these items to the play-frame.

*Never allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using the Triclimb and accessories.

*Do not allow children to wear open toe or heel footwear like sandals or flip-flops whilst climbing.

*Do not permit rough play or use of equipment in a manner for which it was not intended. Jumping from the top, elevated rungs could be dangerous.

*Observe capacity limitations of your play-frame - 1 user maximum.

* Recommended age: 0+ Weight limit 100kg

*Not suitable for children under 36 months until fully assembled – fall hazard and small parts – choking hazard.

*WARNING – periodically check pins to make sure they are not proud.



WARNING: ADULT ASSEMBLY IS REQUIRED

CARE INSTRUCTIONS

Caring for your Tri Climb accessory is not only essential for improving safety, but will also add years to its life for your children to play on and enjoy as they grow.

WARNING: If the checks and maintenance of the Triclimb and accessories are not carried out they could become a hazard.

*It is important to check your Triclimb and accessories for wear and damage before use. If you are unsure as to the integrity of any component, replace it immediately.

*We recommend that you regularly check your Triclimb and accessories for splits, broken or cracked wood, missing, loose or sharp edged hardware – replace, tighten and/or sand smooth as required prior to playing.

*The wooden components are manufactured from FSC birch plywood and solid timber poles; they are protected with a durable child/toy-safe finish.

*To clean, wipe with a damp cloth and mild detergent. Dry immediately. Leaving water or cleaning agent on the surface may damage the finish. Do not use abrasive cleansers.

* Do not modify the unit. Triclimb Ltd is not responsible for any injury arising as a result of modifications made by customers to our products without our supervision, testing, or evaluation.

IPO - Registered design.

Model – MS

Designed and Manufactured by Triclimb Ltd.
Triclimb Ltd. Ty Gelert, Porthmadog, LL499NX
Triclimb NI, PO Box 620, CRAIGAVON BT64 9EL

www.triclimb.co.uk hello@triclimb.co.uk

UKCA, EU, ASTM, CPSC, ISO, SOR tested and approved